



# **POSTLE INDUSTRIES, INC.**

P.O. Box 42037 • Cleveland, Ohio 44142

Fax: 216-265-9030 • Phone: 216-265-9000 • Toll Free: 800-321-2978

E-Mail: sparky@postle.com • Web Site: www.postle.com

## **POSTALLOY® A-Max Wear Plate Installation**

- Identify the areas that experience high wear and impact.
- Identify how large the area is to be plated.
- Make a draft of the area to be plated and determine what size plates should be used. Possibly a combination of sizes is best.
- Plug weld using Postalloy® 301 or 305 electrodes, or Postalloy® 30-FCG or 3044-FCG wire.

### **Installation:**

1. You should work from the inside out and plug weld the plates in place.
2. The inside corners should be plugged next.
3. The outer corners should be the last to be plugged.

